

ANCHOR INFORMATION

TYPE	APPLICATION	PLACEMENT	SIZE
ASPHALT ANCHOR	For installation on asphalt	Typically spaced 10' - 15' apart	30"
CONCRETE ANCHOR	For installation on concrete	Typically within 6" away from 1 side of each leg	6"
EARTH AUGER ANCHOR	For installation of any unit on the ground, whether it be on soil, gravel, etc.	Typically spaced 10' - 15' apart	30"
REBAR ANCHOR	Pins baserail in place during construction	Typically spaced 10' apart	30"

**If proper anchoring is not possible, building will not meet rating criteria.*



FLUSH MOUNT KIT

The flush mount kit allows you to use a concrete pad the same size as the building itself without extending beyond 2" or more. Example: for a 20'x30' building you would need a 20' x 30' concrete pad.




CONCRETE ANCHORS

Sometimes referred to as wedge anchors, contractors drill into the concrete and insert the anchor to fasten the building very securely to the concrete pad.



REBAR ANCHORS


Used in combination with every other anchor style except for concrete. Rebar anchors hold the baserail in place during construction to ensure a sturdy installation.



EARTH AUGER ANCHORS

also known as Mobile Home Anchors

Used to secure the building in ground installations only. They are double helical in design.



ASPHALT ANCHORS

Used in asphalt installations only. They have 4 fins that when driven into the ground hold the anchor in keeping the building secure during high wind conditions.